

SIMPSON**Strong-Tie**

STEEL STRONG-WALL® PORTAL KIT

Installation Instructions

Align the notches on the SSWPS straps with the bottom of the header (as shown). Attach to the header using 10d x 2½" nails (min.) and to the Steel Strong-Wall using #14 x 1" hex head, self-drilling screws (provided), starting with the top screw and working down. Adjust the strap as necessary to avoid overlap with existing holes on the Steel Strong-Wall.

Alinear las ranuras de los flejes SSWPS con la parte inferior del cabezal (como se muestra). Fijar al cabezal usando clavos 10d x 2 ½" (mín.) y a la pared de acero Strong-Wall usando tornillos autoperforantes de cabeza hexagonal #14 x 1" (incluidos), comenzando por el tornillo de arriba y trabajando hacia abajo. Ajustar como sea necesario para evitar superponer los agujeros existentes en la pared de acero Strong-Wall.

Aligner les encoches qui sont sur les brides du connecteur SSWPS sur la partie inférieure du linteau (comme illustré). Fixer le connecteur au linteau avec des clous 10d x 2½" (minimum) et au Steel Strong-Wall avec les vis autotaraudeuses à tête hexagonale no 14 x 1" (fournies) en commençant par la vis du haut et en procédant vers le bas. S'assurer de ne pas chevaucher les trous existants sur le Steel Strong-Wall.

