

# SCHEMATIC AND PARTS FOR THE PTP-27ASMAGR AND PTP-27ALMAGR TOOLS

## PTP-27ALMAGR PARTS LIST:

Pos.	Description	Drawing No.
3	Long Barrel Complete	PTP-852100.0
4	Long Nosepiece	PTP-750001.1
5	Long Magazine Complete - Long Magazine Compl.751000.0 + Long Nosepiece 750001.0 + Long Piston 852001.0 + Piston Disc 752002.0 + Long Rubber Returner 752003.0	PTP-751000.0
37	Long Piston	PTP-852001.0
39	Long Rubber Returner	PTP-752003.0

## PTP-ASMAGR PARTS LIST:

Pos.	Description	Drawing No.
3	Short Barrel Complete	PTP-842100.0
4	Short Nosepiece	PTP-740001.0
5	Short Magazine Complete -short Magazine Compl.741000.0 + Short Nosepiece 740001.0 + Short Piston 842001.0 + Piston Disc 752002.0 + Short Rubber Returner 742003.0	PTP-741000.0
37	Short Piston	PTP-842001.0
39	Short Rubber Returner	PTP-742003.0

## PTP-27ASMAGR AND PTP-27ALMAGR PARTS LIST:

Pos.	Description	Drawing No.
1	Handle - Body	PTP-760001.0
2	Receiver	PTP-860002.0
6	Trigger Lever	PTP-514034
7	Trigger Lever Pin Ø3x30	PTP-M85027
8	Trigger	PTP-514023
9	Advance Lever Spring	PTP-514030
10	Advance Lever	PTP-514021
11	Slide Screw	PTP-760011.0
12	Slide	PTP-760012.0
13	Slide Spring	PTP-760013.0
14	Regulator Cover	PTP-914590
15	Regulator Cover Screw (2)	PTP-BN11288
16	Regulator Bolt	PTP-914020
17	Regulator Nut	PTP-914021
18	Regulator Shock Absorber Steel Insert	PTP-720061
19	Regulator Shock Absorber Rubber	PTP-914610
20	Firing Pin Mech.	PTP-514008
21	Pushing Pin	PTP-514022
22	Firing Pin Sear	PTP-514020
23	Firing Pin Sear Spring	PTP-514026
24	Firing Pin Complete	PTP-514010
25	Mech. Spring	PTP-514027
26	Firing Pin Spring	PTP-514029
27	Receiver Plug	PTP-514009
28	Plug Cover	PTP-614004
29	Cushion Handle	PTP-614017
31	Handle Screw Ø3x16 (2)	PTP-PNM83104
32	Handle Screw Ø3x25 (5)	PTP-PNM83105
33	Handle Screw Ø3x30 (3)	PTP-PNM83106
34	Nut M6	PTP-M82302
35	Bolt M6 x12	PTP-M82154
36	Nosepiece Screw	PTP-750002.0
38	Piston Disk	PTP-730071CH

